


## Repair instruction

**Description:** C200 Lip seal Cassette  
**Part number:** 23721  
 Look for Service Centers, Point of Sale addresses and other information on: [www.thetford-europe.com](http://www.thetford-europe.com)

<b>Version:</b>	V2
<b>Date:</b>	13/07/2006
<b>Tools required:</b>	

**A**

Remove the sliding Cover.


2 screw covers. **Note:** Lever off gently screw covers located on either side of the seal cover.



**B**

Unscrew the 8 screws on the seal cover and, take the seal cover off.


When placing the lip seal on the waste tank, the thinner flange has to face downwards the blade.



**C**

Place the lip seal on the waste tank.

Screw the seal cover back onto the waste tank.



**D**

Press both screw covers back on the seal cover.

Place sliding cover back on its place. Make sure that the two arrows are pointed to each other.

